


OS-382N GAV HAVALI BANT ZIMPARA



No.	Parça Adı	Adet	No.	Parça Adı	Adet
1	Cap	1	31	Spring	1
2	Ball Bearing	1	32	Block Slice	1
3	End Plate A	1	33	Drive Pulley	1
4	Pin	1	34	Key	1
5	Cylinder	1	35	Washer	1
6	Rotor	1	36	Screw	1
7	Rotor Blade	5	37	Belt Guard	1
8	Spacer	1	38	Handle Screw	1
9	End Plate B	1	39	O-Ring	1
10	Ball Bearing	1	40	Screw	1
11	Housing	1	41	Dust Cover	1
12	Lever Pin	1	42	Ball Bearing	2
13	SPRING	1	43	Idle Pulley	1
14	Valve Stem	1	44	Bracket 10	1
15	O-Ring	1	45	Screw	1
16	O-Ring	1	46	Screw	1
17	O-Ring	2	47	Pin	1
18	Valve Body	1	48	Sping Pin	1
19	Safety Lever	1	49	Lever Pin	1
20	Cover Handle	1	50	Spring	1
21	Washer	1	51	Tension Bar 10	1
22	Fabric Silencer	1	52	Shoe 10	1
23	Exhaust Control Spacer	1	53	Screw	1
24	Inlet Bushing	1	54	Hexagon Wrenchen Key (3mm)	1
25	Washer	1	55	Hexagon Wrenchen Key (1.5mm)	1
26	Spring	1	56	O-Ring	1
27	Guide Cover	1	57	Spring	1
28	Guard Body	1	58	Fabric Silencer	1
29	Screw	1	59	Sandpaper Belt #100	1
30	Set Screw	1			

Bi Dünya Havalı

Havalı El Aletleri Satış & Teknik Servis Tel:
0536 451 11 88