


OS-60PB **GAV** HAVALI SHUT-OFF TORNAVİDA



NO.	PARÇA ADI	ADET	NO.	PARÇA ADI	ADET
1	End Housing (Blue)	1	34-2	Washer	1
2	O Ring	1	35	Air Inlet Bushing [NPT]	1
3	Valve	1	36	Retainer	1
4	Set Screw And Washer	1	37	Ball	32
5	Switch	1	38	Pilot Pin	1
6	Ball Bearing	1	39	Rear Clutch	1
7	End Plate	1	40	C Ring	1
8	Pin	1	41	Center Clutch	1
9	Pin	1	42	Ball	2
10	Cylinder	1	43	Anvil (6.35Hex)	1
11	10T Rotor	1	44	Ball	2
12	Blade	5	45	Spring	1
13	Front Plate	1	46	Slide Base	1
14	Ball Bearing	1	47	End Clutch	1
15	C Ring	1	48	Ball	25
19	15T Plant Gear	4	49	Ball Race	1
20	Fifth Gear Cage	1	50	C Ring	1
21	10T Main Gear	1	51	Torque Spring	1
22	15T Plate Gear	4	52	Washer	1
23	Fifth Gear Cage	1	53	Anvil Bushing	1
24	Internal Gear	1	54	Clutch Housing	1
25	Center Housing (Blue)	1	55	Needle Pin	3
26	Ball Bearing	1	56	Regulation Washer	1
27	O Ring	1	57	Torque Ring	1
28	Silencer	1	58	Spring	1
29	Exhaust Deflector	1	59	Ball	1
30	O Ring	1	60	Bit Slide Sleeve	1
31	Valve Plate	1	61	C Ring	1
32	Operating Rod	1	62	Rear Housing	1
33	Cone Spring	1	64	Suspension Ring	1
34	Silencer	1	65	Soft Cover	1
34-1	O Ring	1			

Bi Dünya Havalı

Havalı El Aletleri Satış & Teknik Servis
Tel: 0536 451 11 88