

OS-6338GL **GAV** HAVALI MATKAP




FIG NO.	PART NO.	DESCRIPTION	PCS	FIG NO.	PART NO.	DESCRIPTION	PCS
1	389501	Inlet Bushing	1	21	633818	Front Plate	1
2	633802	Deflector	1	21-1	633842	Spring Pin (2.5X4)	1
3	389503	Valve Spring	1	22	633843	Pin	1
4	328804V	Valve	1	23	633820	Idle Gear	3
5	328835	Valve Seat	1	24	633821	Pin	3
6	328825S	Spacer	1	25	633822	Spindle	1
7	389507	Silencer	1	26	633826	Ball Bearing (6201ZZ)	2
8	633808-SA	Composite Housing	1	27	633824	Ring Gear	1
9	633809	Reverse Valve Lever	1	28	633825	Front Housing	1
9-1	633809-1	Screw	1	29	633830	3/8" Drill Chuck	1
10	633810-1	Trigger	1	30	633831	Chuck Screw	1
10-1	638013	O-Ring	1				
11	633811	O-Ring	2				
12	633812	Valve Body	1				
13	633847	Spring	1	**29	633830L	3/8" Keyless Chuck	1
14	SB0003-1	Detent Ball	1				
15	B626ZZ	Ball Bearing (626ZZ)	2				
16	633813	Rear Plate	1				
17	633817-1	Guide Pin	1				
18	633815	Rotor	1				
19	633816	Rotor Blade	5				
20	633817	Cylinder	1				

Bi Dünya Havalı

Havalı El Aletleri Satış & Teknik Servis
Tel: 0536 451 11 88