


# OS-9313 GAV HAVALI TORNAVİDA



Part NO.	Description	Q' ty	Part NO.	Description	Q' ty	Part NO.	Description	Q' ty
01-102-02	ROTOR BLADE	5	15-701-02	BALL BEARING (695-2Z)	1	38-502-01	CYLINDER	1
02-200-02	O-RING (P3.5x1.5)	1	15-701-07	BALL BEARING (626)	1	39-701-10	BOLT	1
02-200-04	O-RING (P4x1.9)	1	15-702-02	BALL BEARING (608)	1	48-703-03	GEAR RING	1
02-200-07	O-RING (P8x1.5)	2	15-702-07	BALL BEARING (6000-2Z)	1	49-702-01	GEAR SEAT	1
02-202-02	O-RING (P23.5x2)	2	16-701-03	GEAR	2	51-401-04	BUSHING	1
03-700-02	STEEL BALL (φ 2.5mm)	12	17-707-01	SWITCH LEVER	1	51-402-06	BUSHING	1
03-700-04	STEEL BALL (φ 4mm)	4	18-702-03	REVERSE VALVE	1	51-501-02	BUSHING	1
03-700-07	STEEL BALL (φ 3.175mm)	1	21-502-01	WASHER	1	52-700-01	WASHER	1
04-701-02	PIN (φ 4x13)	2	21-701-01	RING	1	52-702-01	WASHER	1
04-701-04	PIN (φ 2x14)	1	24-702-02	VALVE ROD	1	52-702-09	WASHER	1
05-702-03	PIN (φ 3x24)	1	25-702-05	AIR INLET (PT)	1	65-701-01	RING	1
06-700-05	SPRING	1	26-703-01	MUFFLER	1	73-502-01	CLUTCH	1
06-701-13	SPRING	1	26-902-02	MUFFLER	1	74-704-07	DRIVING ROD	1
08-700-01	SPRING	1	31-707-03	HOOK	1	74-705-06	ANVIL	1
08-700-02	SPRING	1	35-706-04	ROTOR	1	75-607-04	FRONT CAP	1
11-702-01	RETAINING RING	1	36-502-01	FRONT PLATE	1	78-610-01	HANDLE	1
13-701-10	SCREW	1	37-502-01	REAR PLATE	1			

**Bi Dünya Havalı**

Havalı El Aletleri Satış & Teknik Servis  
Tel: 0536 451 11 88